

## How do I set the right Time?

1. Switch on the Beyonwiz PVR and wait for a picture to show on the screen. If a picture doesn't appear, your PVR may need to scan your channels first – See "How do I do a Channel Scan?"



2. Press the SETUP button on the remote

3. Using the ARROW keys on the remote, navigate to the CONFIG option on the top bar.

4. Make sure the highlighted item is Time on the left column and press OK on the remote – the highlighted item should now be Mode.

*Note: There are two different modes, AUTO and MANUAL.*

*The simplest way of keeping the time correct is to set the mode to AUTO.*

5. Press OK on the remote then use the ARROW keys to highlight >AUTO then press OK.



6. Use the ARROW keys on the remote to navigate down the list to Time Offset and press OK.

7. Use the ARROW keys on the remote to highlight the time offset for your region (see table below) and press OK


Zone	Time Offset	Daylight Saving
Eastern	+10:00	+11:00
Central	+09:30	+10:30
Western	+08:30	+09:00



8. The current time and date should now be correct and can be seen opposite the Current Time Label.

9. Press the LIVE button to return to normal viewing

*Note: You can also change the time and date format if you prefer 24 hour time and different day month year layout*



FOR MORE DETAILED INFORMATION REFER TO PAGE 22 OF THE MANUAL