

How do I setup and use Favorites?

*Note: Favorites are an easy way to “group” channels together ie HD Group or SD Group, so that it is easy to find the channel you want. Once you’ve grouped the channels, you can list them with the **FAV** button.*

1. Switch on the Beyonwiz PVR and wait for a picture to show on the screen. If a picture doesn't appear, your PVR may need to scan your channels first – See “How do I do a Channel Scan?”
2. Press the **SETUP** button on the remote
3. Using the **ARROW** keys on the remote, navigate to the **MISC** option on the top bar.
4. Make sure the highlighted item is **Favorite** (left column) and press **OK** on the remote – the highlighted item should now be **Group**.
5. Press the **RED** button on the remote to create a new **Group**
6. Use the **ARROW** keys to highlight a **letter**, then the **OK** button to enter it. The letter should appear on the top line. Continue this process to create the group name.

When you've finished entering the new **Group** Name, use the **ARROW** keys to highlight **Save and Exit** and press **OK**.



*Note: You can switch **Caps Lock** on and off using the **RED** button. The **Circle Arrow** button is **Backspace***

7. Use the **ARROW** keys on the remote to navigate across to the **All Service** list of channels (right hand column) and highlight the channel you want included in the group.
8. Press **OK** to add it to the **Fav. Service** (centre column).



*Note: to remove a channel from the Fav. Service use the **ARROW** keys on the remote to navigate across to the channel in the Fav. Service column and press **OK***

9. Continue adding channels you want in that group.
To add more groups go back to step 5.
10. When finished press the **LIVE** button to return to normal viewing
11. Bring up the **Favorite Group** list by pressing the **FAV** button on the remote; use the **ARROW** keys to highlight the group, then the channel you wish to view and press the **OK** button.

