

## How do I rename a recorded file?

*Note: Once you have recorded a number of TV shows, you may want to change the name to something that you can relate to. This tutorial assumes you already have some recorded files on the HDD.*

1. Switch on the Beyonwiz PVR and wait for a picture to show on the screen. If a picture doesn't appear, your PVR may need to scan your channels first – See "How do I do a Channel Scan?"
2. Press the **FILE PLAY** button (next to **LIVE**) on the remote to bring up the **Media Player**.
3. Press the **◀▶ ARROW** keys to move to **Movie** (listed top left)
4. Press the **▲▼ ARROW** keys to move to **HDD** and press **OK**.
5. Press **OK** to open the **recording** folder.



6. Use the **▲▼ ARROW** keys to highlight a file you want to rename and press the **POP-UP** button on the remote.
7. Use the **▲▼ ARROW** keys to highlight **Rename**



8. Use the **ARROW** keys to highlight a **letter**, then the **OK** button to enter it. The letter should appear on the top line. Continue this process to rename the file.

When you've finished renaming the file use the **ARROW** keys to highlight **Save and Exit** and press **OK**.

*Note: You can switch **Caps Lock** on and off using the **RED** button. The **Circle Arrow** button is **Backspace***

*You can enter numbers using the number keys on the remote*



FOR MORE DETAILED INFORMATION REFER TO PAGE 82 OF THE MANUAL